Installation Engineering Handbook 30
Western Electric Company, Incorporated
Service Division

Section 1C
dated 1-24-72
Replaces: Section 1C
dated 8-22-69

LOCATION, ERECTION AND ASSEMBLY

CROSS REFERENCE BETWEEN BSP FIGURES AND HANDBOOK SECTIONS

This section lists numerically the BSP figure numbers referred to in the various sources of job information and the associated handbook section and/or sections in which they will be found. The BSP figures are arranged consecutively in each section. Where more than one handbook section is listed, reference to any one will be satisfactory as the BSP figure is the same in each section. If a BSP figure is referred to in the job information and is not listed below, it is not yet contained in the Handbook and should be requested by means of a Route "I" J.I.M.

BSP Number	BSP Figure Number	Handbook Section Number
800-610-155 (AA61[illegible].006)	1,2,2A,2B,3,5,6,7, 8,8B,8C,9,9A,9B, 9C,9D,9E,9F,9G,9H, 9J,9L,9M,9N,10A, 11,12,12A,12B,12C, 12D,12E,12F,12G, 12J,12K,12L,12M, 12N,12Q,12R,12S, 12T,12U,12V,12W, 12X,24,25,26,27, 28,29,30,31,32,33, 34,35,36,37,38,39, 39A,40,40A,41,42	17A
	12P,13,14,14A,15, 15A,15B,15C,15D, 15E,15F,16A,16B, 17A,17B,17D,19, 19E,19F,20,21B, 21C,21D,21E,21F, 43,44,45	17B
800-614-154 (AA614.004)	1	20B1,30A
	1A	19E2,27A
	2	30A
	3	19E1,19E3,20B1, 30A
	4,4A,4B	30A,30B
	4D	19E1,20B1
	4E	20B1
	6	20A,20B1
	6A	19E2
	7	20B1
	7A	20B1
	7B	19C
	7D,7E,7F	20B1
800-614-155 (AA614.005)	5	19E1,20A1,20A3
	6	19E3,20A3
	6A	20A3
	6F	19E2
	6G	20A2
	6H	20C
	6J,6L,6M,6P,6Q	19E2
	7	20A3
	7A,7B,7C,7D,7E	19E3,20A3
	8	11B

BSP Number	BSP Figure Number	Handbook Section Number
800-614-155 (Cont.) (AA614.005)		
	9	11A
	9A	11A,19E1
	9B,9C	11A
	9D	11B
	9E,9F,9G	11A
	10	11B
	11	19E1
	11A	11B
	11B,11C,11D,11E, 11F,11G,11H	19E1
	11J	11A,19E1
	11K,11L,11M,12	19E1
	12A	20A1
	12B	20C
	12C,12D,12E,12F, 12G	20A1
	13	19E3
	14,15	20A3
	15A	20A1
	15C	19E1
	15D,15E	20A1
	16	20A3
	16B,16C	20A2
	17	20C
	18,18A,18B,18C, 19,20	11C
	21,22,22A,23,23A, 24,25,25A,26	11B
800-614-156 (AA614.006)	1,2,3,4,5,6,6A,7, 8,9,10,11,12,12A, 13,14,15,16,16A, 17,18,19,20,20A, 21,21A,22,23,24, 25,26,27,28,29	10
	32,33,34,35,36, 36A,37,38,38A	20A
	43	20A3
	44,44A,45,46	20A

BSP Number	BSP Figure Number	Handbook Section Number
→ 800-614-157 (AA614.007)	1, 1B, 1D, 1E, 1F, 1G, 1H, 1J, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 13A, 13B, 13C,	13A 13B
→	13D, 16A, 16D, 17C, 17D, 17E, 17F, 17G, 17H, 18A, 19A, 20A, 21A, 22A, 23, 24, 25, 25C, 26, 27, 28, 28A, 29, 30	
	31, 32, 33, 34, 35, 36, 37, 38, 38H, 38J, 39, 40, 40C, 41, 42, 43, 52, 53, 54, 54E, 54F, 55, 56, 56A, 57, 57A, 57E	13C
	60, 61, 62, 62C, 62G, 62D, 62E, 62F, 62H, 62J	20A3 20A1
	62K	20A3
	62L, 62M	20A1

BSP Number	BSP Figure Number	Handbook Section Number
800-614-157 (Cont.) (AA614.007)	62N, 62P	19E2
	62Q	20A1
	62R	20A3
	63	19E1, 20A3
	63A	20A1
	63B, 63C, 64	20A3
	65, 65B, 65C, 66	13D
	67, 68, 69, 70, 70A, 71, 72, 73, 74, 75, 76, 77, 77B, 78, 79, 80, 81, 82, 83, 84, 85, 86, 87, 88, 89	
800-614-159 (AA614.009)	1, 2A, 3, 3A	40C
	4, 5, 6	40A
	7, 8, 9, 10, 11, 11A, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29	40B

→ Arrowed lines indicate new or changed information.

Assistant Manager
Common Installation Engineering

Reason for Reissue:
General Update of Section.